

Attuatore a relè

Manuale di istruzioni



Sommario

- 3 – Introduzione
- 4 – Descrizione e specifiche prodotto
- 5 – Installazione
- 6 – Funzionamento
- 6 – Garanzia

Introduzione

SmartDHOME vi ringrazia per aver scelto questo dispositivo attuatore a relè di tipo on/off per l'automazione degli impianti.

Il presente modulo è un dispositivo certificato Z-Wave, compatibile con qualsiasi rete abilitata Z-Wave.

Tutti i dispositivi Z-Wave alimentati dalla rete elettrica svolgono anche la funzione di ripetizione di segnale per i dispositivi alimentati a batterie, aiutando ad eliminare possibili zone d'ombra del segnale.

Il presente modulo relè attiverà un contatto on/off del dispositivo collegato in base alle istruzioni / regole definite sul gateway a cui è stato connesso.

Grazie al suo speciale design il modulo a relè può essere inserito all'interno delle scatole elettriche.

Il presente modulo svolge anche la funzione di ripetitore di segnale.

Descrizione e specifiche prodotto

Il presente dispositivo è stato studiato per un utilizzo interno.

Specifiche

Protocollo: Z-Wave.

Frequenza di trasmissione: 868.42 MHz.

Portata del segnale: 30 m in campo aperto.

Temperatura di funzionamento: -15°C ~ 60°C.

Tensione operativa: 230 Vac.

Potenza massima collegabile: 2.400 W.

Dimensione: 32 (A) * 38 (L) * 22 (P) mm.


Contenuto confezione

1 Attuatore a relè on/off.

1 Manuale di istruzioni.

Installazione

1. Seguire lo schema sottostante per l'installazione dell'Attuatore a relè:



2. Per l'inclusione nel gateway: posizionare l'interfaccia in modalità di inclusione e seguire le istruzioni indicate per aggiungere il dispositivo a relè. Il dispositivo è stato predisposto per autoincludersi. L'inclusione in modalità manuale avviene accendendo l'interruttore on/off per 4 volte, infine il dispositivo è incluso nel sistema. Per l'esclusione del dispositivo dal sistema a cui è connesso: posizionare l'interfaccia gateway in modalità esclusione e seguire i passaggi indicati per escludere il dispositivo. Quindi accendere l'interruttore on/off per 4 volte, a questo punto il dispositivo è escluso dalla rete.

Funzionamento

Accendere o spegnere l'utenza collegata mediante l'interfaccia Z-Wave a cui è connessa. Manualmente accendere o spegnere l'interruttore della linea.

Garanzia

Visita il link:

<http://www.ecodhome.com/acquista/garanzia-e-riparazioni.html>



SMARTDHOME

SmartDHOME Srl
www.ecodhome.com
info@smartdhome.com

On/Off Actuator Installation Manual



Summary

- 9 – Introduction
- 10 – Product description and specification
- 11 – Installation
- 12 – Operation
- 12 – Limited warranty

Introduction

Thanks for choosing the Smartdhome actuator for pairing with the home automation gateway.

This device is a Z-Wave enabled device and is fully compatible with any Z-Wave enabled network. Every mains powered Z-Wave enabled device acts as a signal repeater and multiple devices result in more possible transmission routes which helps eliminate “RF dead-spots”

This device will send an On/Off signal to the appliance to which it is attached, on receiving Z-Wave signal from controller or manual switch. Its compact design, means it will fit into most electric compartments. This device also acts as repeater.

Product description and specification

For indoor use only.

Specification

Protocol: Z-Wave.

Frequency range: 868.42 MHz.

Operating range: 30 m uninterrupted.

Operating temperature: -15°C ~ 60°C.

Operating voltage: 230 Vac.

Resistive load: 2.400 W.

Dimensions: 32 (H) * 38 (W) * 22 (D) mm.


Package contents

1 On/off actuator / single relay.

1 Installation manual.

Installation

1. Follow the wiring diagram to install the On/off actuator:



2. For "Inclusion" to a network: Put the Z-Wave Interface Controller into "inclusion" mode, and follow its instruction to add the on/off module to your controller. Auto-inclusion is built into the device. For manual inclusion, turn the switch On/Off 4 times then the device will be included.
For "Exclusion" from a network: Put the Z-Wave Interface Controller into "exclusion" mode, and follow the instructions to remove the on/off actuator from your controller. Turn the switch On/Off 4 times, then the device will be excluded.

Operation

Turn on or off the appliance that is attached to the actuator using the Z-Wave Interface Controller, or manually turn on or off.

Limited warranty

Visit our website:

<http://www.ecodhome.com/acquista/garanzia-e-riparazioni.html>



SmartDHOME Srl
www.ecodhome.com
info@smartdhome.com

For United Kingdom and Ireland only, refer to:

www.ecodhome.co.uk
info@smartdhome.co.uk